


If you are experiencing difficulties, please refer to our instruction videos before calling the emergency line.

GE 169059 18 QUART ROASTER OVEN



- 1 Lid
- 2 Buffet Server Frame
- 3 Removable Serving Dishes
- 4 Removable Roasting Rack
- 5 Removable Roasting Pan
- 6 Roaster Oven Body
- 7 Lid Rest
- 8 Temperature Control
- 9 Indicator Light



HOW TO USE THE ROASTING OVEN

1. Place the cooking pan in the roaster oven body.
2. Make sure the temperature control is in the OFF position, then plug into a 120 volt AC outlet
3. Turn the roaster on by turning the temperature control to the desired temperature.
4. Preheat for 15 to 20 minutes. (indicator light will turn off when ready).
5. Place the roasting rack into the cooking pan, place the food on the rack and place the lid on the oven.
(Note: not all foods or recipes require the roasting rack).
6. When finished, turn the temperature control switch to OFF and unplug the roaster.
7. Remove the roaster lid with oven mitts.

HOW TO USE THE BUFFET SERVER

1. Fill the removable roasting pan 1/2 - 3/4 full with water and place inside the oven body.
2. Place the buffet server frame on top of the cooking pan and add empty serving dishes.
3. Cover the roaster oven with the lid and plug the roaster into a 120 volt AC outlet.
4. Preheat roaster on 350 degree for 30 minutes.
5. Lift lid with oven mitt and carefully add already cooked, hot food into serving dishes.
6. Replace lid and turn control to 250 degrees to keep foods warm.
7. Periodically check and carefully add more hot water if necessary.